

WARNING - BOBCAT SWEEPER SAFETY

Any piece of equipment can be dangerous if not operated properly. **YOU** are responsible for the safe operation of this equipment. The operator must carefully read and follow any warnings, safety signs and instructions provided with or located on the equipment. Do not remove, defeat, deface or render inoperable any of the safety devices or warnings on this equipment, **IF** any safety devices or warnings have been removed, defeated, defaced, or rendered inoperable, **DO NOT USE THIS EQUIPMENT!!!**

⚠ WARNING: This product can expose you to chemicals including naphthalene and chromium from petroleum products which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65warnings.ca.gov

DANGER: This equipment has multiple pinch points that can cause dismemberment or death. Keep hands, feet and all other body parts clear at all times.

NEVER TOUCH A LEAKING HYDRAULIC HOSE IT CAN PIERCE YOUR SKIN! Escaping hydraulic oil under pressure can have sufficient force to penetrate your skin, causing serious personal injury. If injured by escaping fluid, obtain medical treatment immediately!

WARNING! Always wear Eye and Dust Protection whenever operating this equipment!

WARNING: THE EQUIPMENT PROTECTION PLAN DOES NOT COVER DAMAGE TO HOSES AND FITTINGS. CUSTOMER IS RESPONSIBLE FOR ALL HOSE AND FITTING DAMAGE!

DANGER: Exercise special care whenever entering or exiting a skid steer loader with an auxiliary attachment installed. Hoses, mounting brackets, and even the attachment itself can be a trip hazard and could cause you to fall.

OPERATING THE BOBCAT SWEEPER



BRUSH ROTATION

Toward Loader ↖

Away from Loader ↗

TRAVEL DIRECTION

Reverse ←

Forward →

CUTTING EDGE HEIGHT

On Surface

Above Surface**

**** Reduces wear on cutting edge and reduces scratching of swept surface.**

WARNING! AVOID INJURY OR DEATH LIFT RESTRICTION:

DO NOT LIFT SWEEPER MORE THAN 3 FEET. TIPPING CAN RESULT.

LOWER SWEEPER TO GROUND AND STOP ENGINE BEFORE CLEANING, SERVICING, OR REPAIRING.

- **Sweeping Procedure:** With the operator in the loader seat, seat belt fastened, and seat bar lowered, start the engine. Raise the sweeper attachment just off the ground and move to the starting point. Lower the sweeper slowly to the surface. Make sure the cutting edge of the sweeper bucket is just above the surface, level with the surface and the brushes are in contact with the surface. Put the loader lift arms in the float position.
- Engage the auxiliary hydraulics into detent position to rotate the broom forward or reverse, depending on application from above chart.
- Start moving the loader forward, with the broom rotating forward and the broom will sweep debris away from the bucket.
- If the debris is packed (or stuck) on the surface and the broom will not sweep it up, reverse broom rotation. Lower the cutting edge to the surface and move the loader backward. The attachment cutting edge will scrape the surface while the broom sweeps the debris into the bucket.

DUMPING THE BOBCAT SWEEPER: Lift the attachment off the ground. Tilt the sweeper attachment forward until it is empty. The broom can be rotated to help empty the attachment. Note Lift Restriction Warning above before dumping or lifting.

If the person receiving this handout will not be the user of the equipment, forward these instructions to the operator. **IF** there is any doubt as to the operation or safety of the equipment, **DO NOT USE!!! CALL A TOOL SHED IMMEDIATELY!!! FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN INJURY OR DEATH**