


WARNING TORO e-DINGO BATTERY POWERED SKID STEER LOADER

SAFETY Any piece of equipment can be dangerous if not operated properly. **YOU** are responsible for the safe operation of this equipment. The operator must carefully read and follow any warnings, safety signs and instructions provided with or located on the equipment. Do not remove, defeat, deface or render inoperable any of the safety devices or warnings on this equipment. If any safety devices or warnings have been removed, defeated, defaced, or rendered inoperable, **DO NOT USE THIS EQUIPMENT!!!**

DANGER CRUSH HAZARD: Never allow your feet or any other body parts under the Operator's Platform they could become trapped and crushed.

 **WARNING:** Operating, servicing, and maintaining this equipment can expose you to chemicals including lead and lead compounds from the power cord, battery posts, terminals, and related accessories, which are known to the State of California to cause cancer and birth defects or other reproductive harm. Wear gloves or wash your hands frequently when servicing your equipment. For more information go to www.P65warnings.ca.gov

Operating Weight 2,342 lbs.

Maximum Rated Capacity 515 lbs.

Do Not operate this tractor on more than a 15-degree slope

Never operate or drive on a slope, this machine is for indoor/interior applications only. Do not operate outdoors or expose machine to rain or inclement weather.

WARNING!

- Never operate power equipment of any kind if you are tired or if you are under the influence of alcohol, drugs, medication or any substance that could affect your ability or judgment. Be alert! If you get tired while operating this equipment, take a break. Tiredness may result in loss of control.
- Never allow children or untrained people to operate the machine. Also keep children, pets, and bystanders away from the work area. Stop the machine if a child, pet, or bystander enters the work area.
- **DANGER:** This equipment has multiple pinch points that can cause dismemberment or death. Keep hands, feet and all other body parts clear at all times.
- Always keep both feet on the operators platform whenever starting, stopping and operating this machine

NEVER TOUCH A LEAKING HYDRAULIC HOSE IT CAN PIERCE YOUR SKIN! Escaping hydraulic oil under pressure can have sufficient force to penetrate your skin, causing serious personal injury. If injured by escaping fluid, obtain medical treatment immediately!

Warning metal conducts electricity. Do Not use this Tractor where it may come into contact with power lines or other electric circuits. Failure to comply to this warning will result in serious personal injury or death. Keep appropriate distances from High Voltage lines. Never use the Tractor as a ground for welding.

Call 811 Before You Dig! Smart digging means calling 811 before each job. One call to 811 gets your underground utility lines marked for FREE.

Always wear eye protection whenever operating this equipment.

Most loader equipment accidents can be avoided by following simple safety precautions. These safety precautions, if followed at all times, will help you operate your loader safely.

The operator's manual is located in the black plastic tube on the side of the machine, there is also a QR Code that will link to the manual. Read and understand it before operating this tractor.

OPERATING INSTRUCTIONS:

- Improper use of a loader can cause serious injury or death.
- **Always keep the bucket or attachment as low as possible whenever moving this loader! Only raise the bucket when you are in position to dump the load and never raise it when you are on any slope! Moving this loader with the bucket or attachment elevated will cause the loader to flip over causing major injuries or death!**
- Do not lift or carry anybody on the loader or in the bucket or attachment.
- Do not walk or work under a raised loader, bucket, or attachment unless it is securely blocked or held in position.
- Move and turn tractor at low speeds.
- Avoid loose fill, rocks, and holes: They can be dangerous for loader operation or movement.
- Be extra careful when working on inclines.
- Avoid overhead wires and/or obstacles when loader is raised.
- Allow for the loader's length when making turns.
- Stop the loader gradually when lowering or lifting the attachment.
- Use caution when handling loose loads.
- Lower loader bucket, or any attachment to the ground when parking or servicing.
- Visually check for hydraulic leaks and broken, missing, or malfunctioning parts before using.
- It is the renter's responsibility to ensure all operators are aware of the safe way of operating the loader.
- Operate up and down slopes with heavy end of unit uphill. Weight distribution changes based on attachments and load. For example, an empty bucket makes the rear of the unit the heavy end while a full bucket makes the front of the unit the heavy end. Most Toro - approved attachments make the front of the unit the heavy end. Avoid starting, stopping, or turning on slopes. If you must turn, keep the heavy end of the unit uphill. Do not park unit on slope without lowering attachment to the ground, returning all controls to neutral position, turning ignition switch to STOP, and applying parking brake.

RECHARGING

Warning: The Customer is responsible for all damages, or loss of production time, resulting from lack of battery charge or lubrication. Check the hydraulic oil and grease points every time you recharge the battery.

- **Do not handle the plug or the charger with wet hands or while standing in water.**
- **Do not charge the batteries in the rain or in wet conditions.**

Contact with water while charging the machine could cause electric shock, causing injury or death.

To reduce the risk of electric shock, this charger has a 3-prong grounded plug. If the plug does not fit into the wall receptacle, do not modify the plug. Choose another grounded outlet.

Do not change the charger or the power-supply-cord plug in any way.

Important: Check the power supply cord periodically for holes or cracks in the insulation. Do not use a damaged cord. Do not run the cord through standing water or wet grass.

Recommended temperature range for charging: 32° to 131°F

Important: Charge the batteries only in temperatures that are within the recommended range.

Note: The charger will not function in temperatures below the minimum or above the maximum temperatures.

1. Park the machine in the designated location for charging.
2. Shut off the machine and remove the key.
3. Ensure that the battery-disconnect switch is in the ON position.
4. Ensure the charger cord is plugged into the machine
5. Plug the other end of the charger cord into a grounded electrical outlet.
6. Observe the InfoCenter to ensure that the batteries are charging.

Note: The InfoCenter shows the battery charge percentage and amperage. Batteries with a lower voltage charge first; once they reach the voltage of the other batteries, all batteries charge simultaneously. The fan may turn on while the machine is charging. When charging is complete, the InfoCenter shuts off.

7. When the machine reaches a sufficient level, disconnect the charger cord from the outlet.
8. Store the cord in the storage compartment.
9. Start the machine.
10. Verify the charge level using the InfoCenter display.

If the person receiving this handout will not be the user of the equipment, forward these instructions to the operator. **If there is any doubt as to the operation or safety of the equipment,**

DO NOT USE!!! CALL A TOOL SHED IMMEDIATELY!!!

FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN INJURY OR DEATH